

Fremax Mazas de Ruedas		
Código Caroya	Código Fremax	Aplicación Principal
0008.46.01	FWB0008	CITROËN: BERLINGO
0013.46.01	FWB0013	AUDI: A3
0043.46.01	FWB0043	FIAT: 500
0051.46.01	FWB0051	CHEVROLET: ASTRA
0052.46.01	FWB0052	CHEVROLET: ASTRA
0053.46.01	FWB0053	CHEVROLET: ASTRA
0054.46.01	FWB0054	CHEVROLET: ASTRA
0056.46.01	FWB0056	CHEVROLET: ASTRA
0059.46.01	FWB0059	HONDA: CIVIC
0080.46.01	FWB0080	SEAT: IBIZA
0081.46.01	FWB0081	SEAT: IBIZA
0118.46.01	FWB0118	CITROËN: C4
0125.46.01	FWB0125	CITROËN: BERLINGO
0130.46.01	FWB0130	HONDA: CIVIC
0190.46.01	FWB0190	FIAT: DOBLO
0199.46.01	FWB0199	CITROËN: C3
0206.46.01	FWB0206	AUDI: A3
0207.46.01	FWB0207	AUDI: TT
0214.46.01	FWB0214	BMW: 116I / 116D
0252.46.01	FWB0252	FORD: FOCUS
0303.46.01	FWB0303	RENAULT: EXPRESS
0318.46.01	FWB0318	FORD: TRANSIT
0331.46.01	FWB0331	ALFA ROMEO: 145
0361.46.01	FWB0361	FIAT: DOBLO
0377.46.01	FWB0377	BMW: 316 E36 / 316I
0398.46.01	FWB0398	FORD: COURIER
0408.46.01	FWB0408	CHEVROLET: ASTRA
0409.46.01	FWB0409	CHEVROLET: ASTRA
0411.46.01	FWB0411	CHEVROLET: ASTRA
0449.46.01	FWB0449	ALFA ROMEO: 145
0478.46.01	FWB0478	TOYOTA: COROLLA
0500.46.01	FWB0500	FIAT: 147
0501.46.01	FWB0501	VOLKSWAGEN: GOL
0502.46.01	FWB0502	HONDA: FIT
0503.46.01	FWB0503	HONDA: FIT
0504.46.01	FWB0504	CHEVROLET: AGILE
0504.46.02	FWB0504-KT	CHEVROLET: CORSA
0505.46.01	FWB0505	FIAT: DUNA
0506.46.01	FWB0506	CHEVROLET: ASTRA
0507.46.01	FWB0507	CHEVROLET: VECTRA
0508.46.01	FWB0508	VOLKSWAGEN: POLO
0509.46.01	FWB0509	ALFA ROMEO: 145
0510.46.01	FWB0510	FIAT: 147
0511.46.01	FWB0511	FIAT: TEMPRA
0512.46.01	FWB0512	FIAT: ARGO
0513.46.01	FWB0513	FIAT: FIORINO
0514.46.01	FWB0514	FIAT: DOBLO
0515.46.01	FWB0515	FIAT: FIORINO
0516.46.01	FWB0516	CITROËN: JUMPER
0518.46.01	FWB0518	FORD: COURIER
0519.46.01	FWB0519	FORD: ESCORT
0520.46.01	FWB0520	CHEVROLET: BLAZER
0521.46.01	FWB0521	CITROËN: C3
0522.46.01	FWB0522	CITROËN: JUMPER
0523.46.01	FWB0523	RENAULT: 19
0524.46.01	FWB0524	VOLKSWAGEN: KOMBI
0525.46.01	FWB0525	VOLKSWAGEN: KOMBI
0526.46.01	FWB0526	VOLKSWAGEN: ESCARABAJO

0527.46.01	FWB0527	SEAT: CORDOBA
0529.46.01	FWB0529	FORD: RANGER
0530.46.01	FWB0530	FORD: RANGER
0531.46.01	FWB0531	CHEVROLET: BLAZER
0532.46.01	FWB0532	VOLKSWAGEN: FOX / CROSSFOX
0533.46.01	FWB0533	FORD: F4000
0534.46.01	FWB0534	TOYOTA: COROLLA
0535.46.01	FWB0535	HYUNDAI: TUCSON
0536.46.01	FWB0536	HYUNDAI: TUCSON
0537.46.01	FWB0537	FORD: F250
0538.46.01	FWB0538	HONDA: CIVIC
0539.46.01	FWB0539	FORD: EXPLORER
0540.46.01	FWB0540	TOYOTA: COROLLA
0541.46.01	FWB0541	HONDA: CIVIC
0542.46.01	FWB0542	HONDA: FIT
0543.46.01	FWB0543	HONDA: CITY
0544.46.01	FWB0544	CHEVROLET: CHEVY
0545.46.01	FWB0545	TOYOTA: COROLLA
0546.46.01	FWB0546	TOYOTA: COROLLA
0547.46.01	FWB0547	CITROËN: JUMPER
0548.46.01	FWB0548	FIAT: DOBLO
0549.46.01	FWB0549	FIAT: MAREA / MAREA WEEKEND
0551.46.01	FWB0551	AUDI: A3
0553.46.01	FWB0553	VOLKSWAGEN: FOX / CROSSFOX
0554.46.01	FWB0554	FIAT: IDEA
0555.46.01	FWB0555	MITSUBISHI: L200 TRITON
0556.46.01	FWB0556	TOYOTA: COROLLA
0557.46.01	FWB0557	HONDA: CIVIC
0558.46.01	FWB0558	HONDA: CITY
0559.46.01	FWB0559	RENAULT: LOGAN
0560.46.01	FWB0560	RENAULT: KANGOO
0561.46.01	FWB0561	FORD: TRANSIT
0562.46.01	FWB0562	NISSAN: FRONTIER
0563.46.01	FWB0563	NISSAN: FRONTIER
0564.46.01	FWB0564	VOLKSWAGEN: SAVEIRO
0565.46.01	FWB0565	CHEVROLET: VECTRA
0566.46.01	FWB0566	VOLKSWAGEN: GOLF
0567.46.01	FWB0567	FIAT: STRADA
0568.46.01	FWB0568	TOYOTA: HILUX
0568.46.02	FWB0568-KT	TOYOTA: HILUX
0569.46.01	FWB0569	TOYOTA: HILUX
0570.46.01	FWB0570	CITROËN: JUMPER
0571.46.01	FWB0571	CITROËN: JUMPER
0572.46.01	FWB0572	IVECO: DAILY
0573.46.01	FWB0573	FIAT: DOBLO
0574.46.01	FWB0574	PEUGEOT: 206
0575.46.01	FWB0575	VOLKSWAGEN: UP
0577.46.01	FWB0577	RENAULT: KANGOO
0591.46.01	FWB0591	TOYOTA: ETIOS
0594.46.01	FWB0594	AUDI: A3
0597.46.01	FWB0597	CHEVROLET: MONTANA
0598.46.01	FWB0598	CITROËN: JUMPER
0599.46.01	FWB0599	RENAULT: SCENIC
0601.46.01	FWB0601	VOLKSWAGEN: GOL
0602.46.01	FWB0602	VOLKSWAGEN: SAVEIRO
0603.46.01	FWB0603	HYUNDAI: I30
0605.46.01	FWB0605	KIA: SPORTAGE
0607.46.01	FWB0607	HYUNDAI: TUCSON
0608.46.01	FWB0608	KIA: PICANTO
0609.46.01	FWB0609	HYUNDAI: ACCENT
0611.46.01	FWB0611	HONDA: CIVIC
0622.46.01	FWB0622	AUDI: A3

0624.46.01	FWB0624	AUDI: A4
0635.46.01	FWB0635	CHEVROLET: CORSA
0636.46.01	FWB0636	CHEVROLET: CAPTIVA
0639.46.01	FWB0639	CHEVROLET: COBALT
0640.46.01	FWB0640	CHEVROLET: COBALT
0641.46.01	FWB0641	CHEVROLET: CRUZE
0642.46.01	FWB0642	CHEVROLET: CRUZE
0643.46.01	FWB0643	CHEVROLET: BLAZER
0652.46.01	FWB0652	CITROËN: XSARA PICASSO
0654.46.01	FWB0654	CITROËN: BERLINGO
0661.46.01	FWB0661	DODGE: RAM 2500
0662.46.01	FWB0662	DODGE: RAM 2500
0666.46.01	FWB0666	DODGE: RAM 2500
0672.46.01	FWB0672	FIAT: DUCATO
0673.46.01	FWB0673	FIAT: DUCATO
0674.46.01	FWB0674	FIAT: DUCATO
0681.46.01	FWB0681	FORD: EXPLORER
0682.46.01	FWB0682	FORD: F4002
0683.46.01	FWB0683	FORD: FOCUS
0684.46.01	FWB0684	FORD: FOCUS
0687.46.01	FWB0687	FORD: ECOSPORT
0688.46.01	FWB0688	FORD: FIESTA
0689.46.01	FWB0689	FORD: FIESTA
0690.46.01	FWB0690	FORD: RANGER
0704.46.01	FWB0704	HONDA: CITY
0714.46.01	FWB0714	HONDA: CIVIC
0717.46.01	FWB0717	HYUNDAI: CRETA
0718.46.01	FWB0718	HYUNDAI: ELANTRA
0719.46.01	FWB0719	HYUNDAI: ELANTRA
0720.46.01	FWB0720	HYUNDAI: SONATA
0722.46.01	FWB0722	HYUNDAI: I30
0728.46.01	FWB0728	HYUNDAI: H100
0729.46.01	FWB0729	HYUNDAI: H101
0736.46.01	FWB0736	KIA: SORENTO
0737.46.01	FWB0737	KIA: SORENTO
0738.46.01	FWB0738	KIA: CERATO
0748.46.01	FWB0748	MITSUBISHI: MONTERO
0749.46.01	FWB0749	MITSUBISHI: MONTERO
0751.46.01	FWB0751	MITSUBISHI: MONTERO
0752.46.01	FWB0752	MITSUBISHI: MONTERO
0755.46.01	FWB0755	NISSAN: SENTRA
0756.46.01	FWB0756	NISSAN: SENTRA
0765.46.01	FWB0765	PEUGEOT: 206
0771.46.01	FWB0771	RENAULT: CLIO
0775.46.01	FWB0775	RENAULT: MASTER
0776.46.01	FWB0776	RENAULT: MASTER
0780.46.01	FWB0780	SUZUKI: VITARA
0783.46.01	FWB0783	TOYOTA: COROLLA
0784.46.01	FWB0784	TOYOTA: COROLLA
0785.46.01	FWB0785	TOYOTA: COROLLA
0787.46.01	FWB0787	TOYOTA: HILUX
0790.46.01	FWB0790	TOYOTA: ETIOS
0791.46.01	FWB0791	TOYOTA: ETIOS
0792.46.01	FWB0792	VOLKSWAGEN: GOL
0793.46.01	FWB0793	RENAULT: GRAND SCENIC
0797.46.01	FWB0797	HYUNDAI: TUCSON
0798.46.01	FWB0798	VOLKSWAGEN: GOLF
0802.46.01	FWB0802	HYUNDAI: SANTA FE
0815.46.01	FWB0815	NISSAN: KICKS
0816.46.01	FWB0816	VOLKSWAGEN: AMAROK
0817.46.01	FWB0817	RENAULT: CAPTUR
0818.46.01	FWB0818	HONDA: CR-V

0820.46.01	FWB0820	FIAT: TORO
0821.46.01	FWB0821	FIAT: 500L
0822.46.01	FWB0822	FIAT: 500L
0824.46.01	FWB0824	HONDA: HR-V
0825.46.01	FWB0825	HONDA: HR-V
0832.46.01	FWB0832	NISSAN: KICKS
0834.46.01	FWB0834	HYUNDAI: CRETA
0836.46.01	FWB0836	RENAULT: MASTER
0847.46.01	FWB0847	CHEVROLET: CRUZE
0848.46.01	FWB0848	CHEVROLET: S10
0849.46.01	FWB0849	CHEVROLET: S10
0880.46.01	FWB0880	FORD: ECOSPORT
0881.46.01	FWB0881	FIAT: TORO
0885.46.01	FWB0885	CHEVROLET: TRACKER
0886.46.01	FWB0886	DODGE: RAM 2500
0891.46.01	FWB0891	IVECO: DAILY
0892.46.01	FWB0892	IVECO: DAILY
0907.46.01	FWB0907	BMW: X3 / X4
0926.46.01	FWB0926	FORD: FOCUS
0931.46.01	FWB0931	CITROËN: JUMPY
0942.46.01	FWB0942	CHERY: TIGGO
0966.46.01	FWB0966	VOLKSWAGEN: POLO
0988.46.01	FWB0988	TOYOTA: HILUX
2610.46.01	FWB2610	TOYOTA: HILUX

***Precios de lista CAROYA expresados en Pesos. Sin IVA.**

**** Descuentos y condiciones habituales, consulte a su vendedor.**